

CashCode Co. Inc.

553 Basaltic Rd. Concord Ontario Canada. L4K 4W8. Phone (905) 303-8874, Fax: (905) 303-8875

VAULT SECURITY LOCK INSTALLATION

1. Open the cassette
2. Remove screws 1 and washers 2.
3. Remove case assembly 6 off the cassette cover 3.
4. Mount the locks and the cams 4 and 5 onto case assembly 6 as shown.
5. Mount the case assembly 6 to its original place (first insert tabs of the case assembly into the holes of the cassette cover than lock it with the screws 1 and washers 2).

IMPORTANT!

Lock Specification:

- Locks should be $\frac{3}{4}$ " DIA size
- Locks should be $1\frac{1}{16}$ " to $1\frac{1}{8}$ " *length* (distance from mounting surface to the cam)
- The angle between the locked and unlocked position of the cam should be 90 degrees in any rotation.

Pay attention to cam 4 orientation for left- and right-turn locks.

