

Proclaim User Manual



This document is the copyright of Money Controls Ltd and may not be reproduced in part or in total by any means, electronic or otherwise, without the written permission of Money Controls Ltd. Money Controls Ltd does not accept liability for any errors or omissions contained within this document. Money Controls Ltd shall not incur any penalties arising out of the adherence to, interpretation of, or reliance on, this standard. Money Controls Ltd will provide full support for this product when used as described within this document. Use in applications not covered or outside the scope of this document may not be supported. Money Controls Ltd. reserves the right to amend, improve or change the product referred to within this document or the document itself at any time.

Contents

1. Diary of Changes	3
2. Setting Up.....	4
3. Starting Up	5
4. Downloading New Firmware.....	6
5. Trouble Shooting	8

Figures

Figure 1: WACS Eagle / Ardac 5 Connections	4
Figure 2: IBA4 / IBA5 Connections	4

Tables

Table 1: Trouble Shooting	8
---------------------------------	---

1. Diary of Changes

Issue 1.0 16th June 2005
➤ First Issue

2. Setting Up

Figure 1: WACS Eagle / Ardac 5 Connections






Figure 2: IBA4 / IBA5 Connections




3. Starting Up

Once the Ardac has powered up and initialised 'Double Click' the Proclaim.exe file or the assigned shortcut.




On start-up you will be presented with the following screen.




4. Downloading New Firmware

NOTE:-

When downloading new firmware, the program will only work through the diagnostics port. Also ensure that a Flash EPROM is fitted.




If re-programming a WACS Eagle / Ardac 5 select 'Diagnostics Port (9 Pin/Flat Black Connector)' as shown below.
If IBA4 or IBA5 is fitted select 'IBA4 (Diagnostics Port)'.




Select the firmware file to be downloaded. Only .A07 files can be used.

Press OK.




The .A07 file will then be checked.

Downloading will then start.



Once downloading has finished, recycle the power for the changes to take effect.



5. Trouble Shooting

Table 1: Trouble Shooting

Fault	Reason	Cure
Comms Error -1	EPROM Fitted	Fit FLASH Device
	No stacker fitted	Enable Bench mode via Hyperterminal.
		Fit stacker and re-cycle power
	ID003 protocol fitted	Enable Bench mode via Hyperterminal. Ensure the unit cycles twice.
	The incorrect protocol is trying to be downloaded. i.e. Ardac 2 is being programmed into a head which was previously setup for Netplex.	Select the correct protocol firmware to download.

This manual is intended only to assist the reader in the use of this product and therefore Money Controls shall not be liable for any loss or damage whatsoever arising from the use of any information or particulars in, or any incorrect use of the product. Money Controls reserve the right to change product specifications on any item without prior notice.