


U3100 MONITOR

Block Diagram



NOTE: HORIZ. FREQUENCY: 31.5KHZ OR 35KHZ
VERT. FREQUENCY: 56 TO 87HZ